

T- CLOCS ITEM	WHAT TO CHECK	WHAT TO LOOK FOR	CHECKOFF
T --- TIRES & WHEELS	Front		Rear
Tires	Condition		Tread depth, wear, weathering, evenly seated, bulges, embedded objects.
Air Pressure	Check when cold, adjust to load/speed	Front	Rear
Wheels	Spokes	Bent, broken, missing, tension, check at top of wheel "ring" OK -- "thud", loose spoke	Front Rear
Cast	Cracks, dents	Front	Rear
Rims	Out of round/true = 5 mm. Spin wheel, index against stationary pointer.	Front	Rear
Bearings	Grab top and bottom of tire and flex: No free play (click) between hub and axle, no growl when spinning.	Front	Rear
Seals	Cracked, cut or torn, excessive grease on outside, reddish-brown around outside.	Front	Rear
C --- CONTROLS	Front		Rear
Levers	Condition		Broken, bent, cracked, mounts tight, ball ends on handlebar lever.
Pivots		Lubricated	
Cables	Condition		Fraying, kinks, lubrication: ends and length.
Routing		No interference or pulling at steering head, suspension, no sharp angles, wire looms in place.	
Hoses	Condition		Cuts, cracks, leaks, bulges, chaffing, deterioration.
Routing		No interference or pulling at steering head, suspension, no sharp angles, wire looms in place.	
Throttle	Operation		Moves freely, snaps closed, no revving.
L --- LIGHTS			
Battery	Condition		Terminals clean and tight, electrolyte level, held down securely.
Vent Tube		Not kinked, routed properly, not plugged.	
Lenses	Condition		Cracked, broken secure, mounted, excessive condensation
Reflectors	Condition		Cracked, broken securely mounted.
Wiring	Condition		Fraying, chaffing, insulation.
Routing		Pinched, no interference or pulling at steering head or suspension, wire looms and ties in place, connectors tight, clean.	

Headlamp	Condition		Cracks, reflector, mounting and adjustment system.	
Aim		Height and right/left.		
O --- OIL				
Levels	Engine Oil		Check warm on center stand, dipstick, sight glass.	
Hypoid Gear Oil		Transmission, rear drive, shaft.		
Hydraulic Fluid		Brakes, clutch, reservoir or sight glass.		
Coolant		Reservoir and/or coolant recovery tank -- cool only.		
Fuel		Tank or gauge.		
Leaks	Engine Oil		Gaskets, housings, seals.	
Hypoid Gear Oil		Gaskets, seals, breathers.		
Hydraulic Fluid		Hoses, master cylinders, calipers.		
Coolant		Radiators, hoses, tanks, fittings, pipes.		
Fuel		Lines, fuel taps, carbs.		
C --- CHASSIS				
Frame	Condition		Cracks at gussets, accessory mounts, look for paint lifting.	
Steering Head Bearings		No detente or tight spots thru full travel, raise fr. Wheel check for play by pulling/pushing forks.		
Swing Arm Bushings / Bearings		Raise rear wheel, check for play by pushing/pulling swing arm.		
Suspension	Forks	Smooth travel, equal air pressure/damping anti-dive settings.	Left	Right
Shock(s)	Smooth travel, equal pre-load/air pressure/ damper settings, linkage moves freely and is lubricated.		Left	Right
Chain or Belt	Tension		Check at tightest point.	
Lubrication		Side plates when hot.		
Sprockets		Teeth not hooked, securely mounted.		
Fasteners	Threaded		Tight, missing bolts, nuts.	
Clips		Broken, missing.		
Cotter Pins		Broken, missing.		
S --- SIDESTAND				
Center stand	Condition		Cracks, bent.	
Retention		Springs in place, tension to hold position.		
Side stand	Condition		Cracks, bent. (Safety cut-out switch or pad if equipped)	
Retention		Springs in place, tension to hold position.		

